

# Standard Set Extrabond

## Standard Setting Adhesive for fixing Porcelain & Natural Stone Tiles.

STANDARD SET EXTRABOND IS A POLYMER MODIFIED, CEMENT BASED WALL AND FLOOR TILE ADHESIVE WITH INCREASED ADHESION AND NON SLIP PROPERTIES. STANDARD SET EXTRABOND HAS BEEN SPECIALLY FORMULATED FOR FIXING A LARGE VARIETY OF TILES SUCH AS CERAMIC, PORCELAIN AND NATURAL STONES TO SOLID SUBSTRATES SUCH AS SAND/CEMENT SCREED, CONCRETE, BRICK/BLOCK AND PLASTER. FORMULATED TO GIVE AN EXTENDED OPEN/WORKING TIME OF APPROXIMATELY 3 HOURS, STANDARD SET EXTRABOND IS IDEAL WHERE LONGER WORKING TIMES ARE REQUIRED. STANDARD SET EXTRABOND WILL ACCEPT LIGHT FOOT TRAFFIC AFTER 24 HOURS AT 20°C, HOWEVER, THIS MAY BE EXTENDED IF TILING TO IMPERVIOUS SURFACES. STANDARD SET EXTRABOND IS SUITABLE FOR USE IN AREAS SUBJECT TO PROLONGED WET CONDITIONS SUCH AS SHOWERS AND WET ROOMS. STANDARD SET EXTRABOND IS SUITABLE FOR USE INTERNALLY AND EXTERNALLY AND IS UNAFFECTED BY FROST AFTER SETTING.

### PREPARATION:

Before starting, all substrates must be clean, dry and strong enough to support the weight of the tiles and adhesive. Remove all dust, dirt, oil, grease and other contaminants that may affect adhesion.

**For information on preparing all types of surface/substrate prior to tiling, please refer to "Substrates" below.**

### APPLICATION:

Only mix small quantities at a time until you have become accustomed to the setting nature of the product. Always mix powder to water and mix to a buttery consistency, never add water after initial mixing, as this will impair the strength of the adhesive. As an approximate guide for powder to water ratio, 20kg of powder requires approximately 4.8 - 5 litres of water. Product that has started to set must be discarded.

#### THIN BED

On a flat, even substrate where dry conditions exist, apply adhesive to substrate as a thin floated coat at a uniform thickness of 3mm and then rib using a notched trowel or spreader. Bed tiles into adhesive using a twisting action ensuring full coverage of adhesive between tile and substrate, also ensuring there are no hollow spaces or pockets of air. Where tiling is subject to frequent wet conditions such as in showers, in addition, apply as a solid bed a thin layer of adhesive to the back of the tile before applying to the substrate.

#### THICK BED

Where substrate conditions do not allow thin bed fixing, Standard Set Extrabond can be applied to a maximum bed thickness of 12mm. Apply adhesive to substrate as a floated coat and then rib using a notched trowel or spreader. Bed tiles into adhesive using a twisting action ensuring full coverage of adhesive between tile and substrate also ensuring there are no hollow spaces or pockets of air. It may be necessary to additionally apply adhesive to the back of the tile.

**When applying tiles that have deep studs on the back, we strongly recommend covering the studs with adhesive. When fixing large format tiles it is highly recommended to skim the back of the tile with a thin 1mm layer of adhesive. This will significantly improve the bond strength.**

Clean surplus adhesive from the tiles and joints as soon as possible as set adhesive will prove very difficult to remove later. Clean tools after use with water.

### ADVANTAGES:

- Ideal for fixing Natural Stones & Porcelain Tiles
  - Polymer Modified
  - Excellent workability and non-slip properties
  - Extended working time
  - Internal & External use
  - 3mm – 12mm bed depth
- Mix with AddFlex to produce a highly flexible adhesive, Class C2 S2**

### TILES:

- Porcelain
- Ceramics
- Terracotta
- Quarry
- Natural Stones
- Mosaics

### SURFACES:

- Plaster
- Plasterboard
- Tile Backer Board
- Cement/Sand render
- Concrete Brick/Block
- Concrete
- Sand/Cement screed
- Existing Tiles
- Flooring grade Asphalt & Bitumen



# TECHNICAL DATA SHEET

## GROUTING:

The tiled area should be left for a minimum of 24 hours at 20°C before grouting. Do not start grouting until the adhesive has set. Impervious surfaces may extend the set time. If you are tiling an area of limited movement, or under floor heating you must use a grout with flexibility, our Flexigrout and Grout 3000 range are highly recommended.

A total time of 24 to 48 hours depending on atmospheric conditions must be considered before allowing light traffic use on tiled floor area. In floor areas where heavy traffic such as pallet trucks or fork lift trucks are in use, allow 7 to 14 days to achieve full set.

## SUBSTRATES:

**Concrete/screed:** Ensure new concrete is confirmed dry via consistent moisture readings across the whole surface. Sand/Cement screeds must have a moisture reading of less than 75% RH before work can commence. If it is a new screed, allow 1 day per mm for drying. Remove any laitance from the surface mechanically and remove all dust ideally by vacuum.

Prime the surface with Primeplus diluted 3 parts water to 1 part Primeplus. **Very porous substrates will require more than one coat.**

**Asphalt/Bitumen:** Make sure surface is free of loose dirt and dust. Prime the surface with Primeplus diluted 1 part water to 1 part Primeplus mixed with a little neat cement or adhesive to form a brush on slurry. Setting time of the adhesive will increase.

**Ceramic tiles:** Remove loose dirt and dust. Prime the surface with Primeplus diluted 1 part water to 1 part Primeplus mixed with a little neat cement or adhesive to form a brush on slurry. The set time of the adhesive will increase.

**Plaster/plasterboard:** New plaster must be allowed to dry for a minimum of 4 weeks. Make sure surface is free of loose dirt or dust. Prime the surface with Primeplus diluted 3 parts water to 1 part Primeplus. It is essential that plasterboard is screwed very firmly. If the plasterboard is fixed to a timber frame and there is concern over movement and/or vibration, Standard Set Extrabond must be mixed with Tilemaster Addflex instead of water.

**Chipboard:** Chipboard must be a minimum of 18mm and must be screwed (not nailed) every 6 inches/150mm centres to the substrate. Ensure there is enough ventilation beneath substrate and that the chipboard has been fitted competently and will take the weight of tiles and adhesive. Make sure surface is free of loose dirt or dust. Apply an undiluted coat of Primeplus to all exposed edges and joints and then prime the remainder of the surface with Primeplus diluted 2 parts water to 1 part Primeplus. Standard Set Extrabond must be mixed with Tilemaster Addflex instead of water when tiling to Chipboard.

**Underfloor heating:** When tiling onto existing underfloor heating you must switch heating off 48 hours prior to tiling to allow substrate to cool sufficiently. When tiling has been completed allow 1 week for full cure of adhesive before switching heating on. Start with a low temperature, gradually increasing temperature over 2 weeks. Standard Set Extrabond must be mixed with Tilemaster Addflex instead of water when tiling to under floor heating

When tiling on to a new electric element underfloor heating system, Tilemaster Adhesives recommend that you use "Levelflex" over the top of the element to give a solid expandable and perfect surface on which to apply tiles. Again, allow one week for full cure before switching the heating on, start with a low temperature, increasing daily over 2 weeks.

**Plywood:** Plywood must be 12mm (minimum), exterior grade, screwed (not nailed) to substrate at 6 inch/150 mm centres. Ensure there is sufficient ventilation beneath substrate and that substrate will take the weight of tiles and adhesive. Make sure surface is free of loose dirt and dust. Prime the surface with Primeplus diluted 3 parts water to 1 part Primeplus. Standard Set Extrabond must be mixed with Tilemaster Addflex instead of water when tiling to plywood.

**T/g Boarding and Floorboards:** Existing tongue and groove boards should be screwed down to the joists every 6 inches/150mm to provide a rigid, flat and adequately braced surface. Ensure there is sufficient ventilation beneath the substrate and that the substrate is strong enough to support the weight of the adhesive and tiles being applied. Make sure surface is free of loose dirt or dust.

Prime the whole surface with neat Primeplus.

Standard Set Extrabond must be mixed with Tilemaster Addflex instead of water when tiling to T & G Boarding and Floorboards.

**Brick/block:** Ensure surface is free of loose dirt and dust. Prime the surface with Primeplus diluted 3 parts water to 1 part Primeplus. The set time of the adhesive will increase.

**Anhydrite/Gypsum Screed:** Ensure the Anhydrite/Gypsum screed is confirmed dry via consistent moisture readings before application. As a guide for drying times, in ideal conditions, allow 1 day per mm up to a depth of 40mm and 2 days per mm for anything above 40mm depth. The residual moisture content must be less than 0.5%. Remove any laitance from the surface mechanically and remove all dust ideally by vacuum.

Anhydrite/Gypsum screeds must be sealed prior to tiling. Apply one coat of Primeplus or Flexmaster diluted with 3 parts water and allow to dry. Once dry, apply a neat coat of Primeplus or Flexmaster and allow to dry before tiling commences.

**Power Floated Concrete:** Ensure the surface has been allowed 7 days to cure. Power floated concrete can leave a loose top layer and/or laitance once it has cured. Remove the loose top layer and any laitance from the surface mechanically or by acid etching and remove all dust and particles ideally by vacuum. Once all laitance has been removed, prime the surface with Primeplus diluted 3 parts water to 1 part Primeplus.

**Vinyl Tiles/Sheet Vinyl:** Ensure the existing vinyl tiles/sheet is firm, stable and well adhered to the substrate to which the vinyl was originally applied to. Make sure surface is free of loose dirt and dust. Prime the surface with Primeplus diluted 1 part water to 1 part Primeplus mixed with a little neat cement or adhesive to form a brush on slurry. Setting time of the adhesive will increase.

# TECHNICAL DATA SHEET

<b>Standard Conformity</b>	Conforms to BS EN 12004 C2 TE
<b>Bed Thickness</b>	3mm – 12mm
<b>Coverage</b>	20kg will cover approximately 5 – 6 metre <sup>2</sup> at 3mm bed application
<b>Open Time/Working Time</b>	Approximately 3 hours at 20°C
<b>Before Grouting</b>	Approximately 24 hours at 20°C. The set time will be increased by lower temperatures and reduced at higher temperatures. * Tiling onto an impervious substrate with a non porous tile will increase the set time.
<b>Storage</b>	Store unopened, clear of the ground in cool, dry conditions and protect from excessive drafts.
<b>Shelf Life</b>	Stored correctly this product has a shelf life of 6 months
<b>Colours</b>	Grey and White
<b>Pack Sizes</b>	20kg
<b>Note</b>	All work must be carried out in accordance with British Standard Code of Practice for floor and wall tiling BS5385

## TECHNICAL NOTES:

Standard Set Extrabond contains a reducing agent to control the level of Chromium VI. When stored correctly the activity of the reducing agent will be maintained and the product when mixed with water will produce no more than ( 0.0002% ) 2ppm Chromium VI of the total weight of the dry cement. Use of the product after the end of the declared shelf life may increase the risk of an allergic reaction.

The information contained on this spec sheet is given voluntarily and in good faith. It is to the best of our knowledge true and accurate; however it may contain information which is inappropriate under certain conditions of use. The company cannot accept responsibility for any loss or damage due to inappropriate use or the possibility of variations of working conditions and of workmanship outside our control.



**Tilemaster Adhesives Ltd.,**

Unit 4 Tomlinson Point, Tomlinson Road, Leyland, Lancashire PR25 2DY

**Tel: +44 (0)845 208 0040 Fax: +44 (0)845 208 0041**



[www.tilemasteradhesives.co.uk](http://www.tilemasteradhesives.co.uk)